

2.4 MAIN COMPONENTS LIST

Refer to figure 1 & 2 and the table below.

| Item | Part Number | Description | Qty |
|------|-------------|----------------------------------|-----|
| 1 | TRM00360 | Standard nose equipment XT1 tool | 1 |
| | TRM00361 | Standard nose equipment XT2 tool | |
| 2 | TP144-171 | Suspension hook | 1 |
| 3 | TRM00227 | Mandrel collector | 1 |
| 4 | 07001-00405 | Oil plug | 1 |
| 5 | 07003-00194 | Seal | 1 |
| 6 | 76003-02008 | Trigger | 1 |
| 7 | TRM00221 | On/Off valve | 1 |

2.5 STANDARD NOSE EQUIPMENT

Refer to figure 2 and the table below.

| Item | XT1 tool Part Number | XT2 tool Part Number | Description | Qty |
|------|-------------------------|-------------------------|---|-------|
| 1a | PRN314 | - | Nose Piece - 2.4mm [3/32"] | 1 |
| | - | PRN614 | Nose Piece - 4.8 mm [3/16"] (fitted on XT2) | |
| 1b | PRN414 | PRN414 | Nose Piece - 3.2 mm [1/8"] (fitted on XT1) | 1 |
| 1c | PRN514 | PRN514 | Nose Piece - 4.0 mm [5/32"] | 1 |
| 1d | TP144-111 | TP144-048 | Nose housing | 1 |
| 1e | TP144-091 | TP144-091 | O-ring | 1 |
| 1f | DPN239-006 | DPN275-001 | Jaw guide | 1 |
| 1g | PRG402-8A | 71210-15001 | Jaws | 1 Set |
| 1h | TP144-117 | TP144-050 | Jaw pusher | 1 |
| 1i | TP144-118 | TP144-088 | Urethane washer | 1 |
| 1j | TP144-119 | TP144-081 | Jaw pusher spring | 1 |
| 1k | TP144-120 | TP143-052 | Mandrel guide | 1 |
| 1l | TRM00167 | TRM00165 | Pulling head | 1 |
| 1m | TP144-113 | TP144-051 | Jaw guide lock | 1 |
| 1n | TP144-114 | TP144-080 | Jaw guide lock spring | 1 |
| 1o | DPN900-004 | DPN900-002 | O-ring | 1 |
| 1p | TRM00238 | TRM00239 | Nose Housing Nut | 1 |

For additional nose equipment please refer to the ProSet® Nose Equipment Manual 07900-09412 or visit www.stanleyengineeredfastening.com/resource-center/document-library

For a full list of tool accessories, please refer to the ProSet Accessories Manual 07900-09413.